

Chapter 10

APPROXIMATIONS FOR ANALOG FILTERS

10.8 Analog-Filter Transformations

Copyright © 2005- by Andreas Antoniou
Victoria, BC, Canada
Email: aantoniou@ieee.org

October 31, 2010

Analog-Filter Transformations

- Given a normalized transfer function obtained by any one of the classical analog-filter approximations, a *denormalized* lowpass, highpass, bandpass, or bandstop transfer function can be obtained by applying a transformation of the form

$$H_X(\bar{s}) = H_N(s) \Big|_{s=f_X(\bar{s})}$$

where $f_X(\bar{s})$ is one of the four standard *analog-filter transformations*.

Standard forms of $f_X(\bar{s})$

Type	$f_X(\bar{s})$
LP to LP	$\lambda\bar{s}$
LP to HP	λ/\bar{s}
LP to BP	$\frac{1}{B} \left(\bar{s} + \frac{\omega_0^2}{\bar{s}} \right)$
LP to BS	$\frac{B\bar{s}}{\bar{s}^2 + \omega_0^2}$

Lowpass-to-Lowpass Transformation

- Consider a normalized lowpass transfer function $H_N(s)$ with passband and stopband edges ω_p and ω_a .

Lowpass-to-Lowpass Transformation

- Consider a normalized lowpass transfer function $H_N(s)$ with passband and stopband edges ω_p and ω_a .
- A denormalized lowpass transfer function can be obtained as

$$H_{LP}(\bar{s}) = H_N(s) \Big|_{s=\lambda\bar{s}}$$

Lowpass-to-Lowpass Transformation

- Consider a normalized lowpass transfer function $H_N(s)$ with passband and stopband edges ω_p and ω_a .
- A denormalized lowpass transfer function can be obtained as

$$H_{LP}(\bar{s}) = H_N(s) \Big|_{s=\lambda\bar{s}}$$

- By letting $\bar{s} = j\bar{\omega}$ and $s = j\omega$, we get

$$|H_{LP}(j\bar{\omega})| = |H_N(j\omega)| \Big|_{j\omega = j\lambda\bar{\omega}}$$

Therefore, the gain (loss) of the denormalized lowpass filter is equal to the gain (loss) of the normalized lowpass filter provided that $\omega = \lambda\bar{\omega}$.

• • •

$$|H_{LP}(j\bar{\omega})| = |H_N(j\omega)| \Big|_{j\omega = j\lambda\bar{\omega}}$$

- Thus points on the $j\omega$ axis of the s plane map onto points on the $j\bar{\omega}$ axis of the \bar{s} plane.

In particular,

• • •

$$|H_{LP}(j\bar{\omega})| = |H_N(j\omega)| \Big|_{j\omega = j\lambda\bar{\omega}}$$

- Thus points on the $j\omega$ axis of the s plane map onto points on the $j\bar{\omega}$ axis of the \bar{s} plane.

In particular,

- the origin of the s plane maps onto the origin of the \bar{s} plane,

• • •

$$|H_{LP}(j\bar{\omega})| = |H_N(j\omega)| \Big|_{j\omega = j\lambda\bar{\omega}}$$

- Thus points on the $j\omega$ axis of the s plane map onto points on the $j\bar{\omega}$ axis of the \bar{s} plane.

In particular,

- the origin of the s plane maps onto the origin of the \bar{s} plane,
- point $j\omega_p$ of the s plane maps onto point $j\bar{\omega}_p = j\omega_p/\lambda$ of the \bar{s} plane,

• • •

$$|H_{LP}(j\bar{\omega})| = |H_N(j\omega)| \Big|_{j\omega = j\lambda\bar{\omega}}$$

- Thus points on the $j\omega$ axis of the s plane map onto points on the $j\bar{\omega}$ axis of the \bar{s} plane.

In particular,

- the origin of the s plane maps onto the origin of the \bar{s} plane,
- point $j\omega_p$ of the s plane maps onto point $j\bar{\omega}_p = j\omega_p/\lambda$ of the \bar{s} plane,
- point $j\omega_a$ of the s plane maps onto point $j\bar{\omega}_a = j\omega_a/\lambda$ of the \bar{s} plane, and

• • •


$$|H_{LP}(j\bar{\omega})| = |H_N(j\omega)| \Big|_{j\omega = j\lambda\bar{\omega}}$$

- Thus points on the $j\omega$ axis of the s plane map onto points on the $j\bar{\omega}$ axis of the \bar{s} plane.


In particular,

- the origin of the s plane maps onto the origin of the \bar{s} plane,
- point $j\omega_p$ of the s plane maps onto point $j\bar{\omega}_p = j\omega_p/\lambda$ of the \bar{s} plane,
- point $j\omega_a$ of the s plane maps onto point $j\bar{\omega}_a = j\omega_a/\lambda$ of the \bar{s} plane, and
- infinity of the s plane maps onto infinity of the \bar{s} plane.

LP-to-LP Transformation – Mapping Properties



LP-to-LP Transformation – Graphical Illustration



Lowpass-to-Highpass Transformation

- The LP-to-HP transformation follows the pattern of the LP-to-LP transformation.

Lowpass-to-Bandpass Transformation

- A denormalized bandpass transfer function can be obtained from a normalized lowpass transfer function as follows:

$$H_{BP}(\bar{s}) = H_N(s) \Big|_{s = \frac{1}{B} \left(\bar{s} + \frac{\omega_0^2}{\bar{s}} \right)}$$

Lowpass-to-Bandpass Transformation

- A denormalized bandpass transfer function can be obtained from a normalized lowpass transfer function as follows:

$$H_{BP}(\bar{s}) = H_N(s) \Big|_{s = \frac{1}{B} \left(\bar{s} + \frac{\omega_0^2}{\bar{s}} \right)}$$

- By letting $\bar{s} = j\bar{\omega}$ and $s = j\omega$, we get

$$|H_{BP}(j\bar{\omega})| = |H_N(j\omega)| \Big|_{j\omega = \frac{1}{B} \left(j\bar{\omega} + \frac{\omega_0^2}{j\bar{\omega}} \right)}$$

Lowpass-to-Bandpass Transformation

- A denormalized bandpass transfer function can be obtained from a normalized lowpass transfer function as follows:

$$H_{BP}(\bar{s}) = H_N(s) \Big|_{s = \frac{1}{B} \left(\bar{s} + \frac{\omega_0^2}{\bar{s}} \right)}$$

- By letting $\bar{s} = j\bar{\omega}$ and $s = j\omega$, we get

$$|H_{BP}(j\bar{\omega})| = |H_N(j\omega)| \Big|_{j\omega = \frac{1}{B} \left(j\bar{\omega} + \frac{\omega_0^2}{j\bar{\omega}} \right)}$$

- Therefore, the gain (loss) of the denormalized bandpass filter is equal to the gain (loss) of the normalized lowpass filter provided that

$$\omega = \frac{1}{B} \left(\bar{\omega} - \frac{\omega_0^2}{\bar{\omega}} \right)$$

• • •

$$\omega = \frac{1}{B} \left(\bar{\omega} - \frac{\omega_0^2}{\bar{\omega}} \right)$$

■ Solving for $\bar{\omega}$, we get

$$\bar{\omega} = \begin{cases} \omega_0 & \text{if } \omega = 0 \\ \pm \bar{\omega}_{p1}, \pm \bar{\omega}_{p2} & \text{if } \omega = \pm \omega_p \\ \pm \bar{\omega}_{a1}, \pm \bar{\omega}_{a2} & \text{if } \omega = \pm \omega_a \end{cases}$$

where

$$\bar{\omega}_{p1}, \bar{\omega}_{p2} = \mp \frac{\omega_p B}{2} + \sqrt{\omega_0^2 + \left(\frac{\omega_p B}{2} \right)^2}$$

$$\bar{\omega}_{a1}, \bar{\omega}_{a2} = \mp \frac{\omega_a B}{2} + \sqrt{\omega_0^2 + \left(\frac{\omega_a B}{2} \right)^2}$$

■ Thus,

$$j\bar{\omega} = \begin{cases} j\omega_0 & \text{if } j\omega = 0 \\ \pm j\bar{\omega}_{p1}, \pm j\bar{\omega}_{p2} & \text{if } j\omega = \pm j\omega_p \\ \pm j\bar{\omega}_{a1}, \pm j\bar{\omega}_{a2} & \text{if } j\omega = \pm j\omega_a \end{cases}$$

- Thus,

$$j\bar{\omega} = \begin{cases} j\omega_0 & \text{if } j\omega = 0 \\ \pm j\bar{\omega}_{p1}, \pm j\bar{\omega}_{p2} & \text{if } j\omega = \pm j\omega_p \\ \pm j\bar{\omega}_{a1}, \pm j\bar{\omega}_{a2} & \text{if } j\omega = \pm j\omega_a \end{cases}$$

- In effect,

- Thus,

$$j\bar{\omega} = \begin{cases} j\omega_0 & \text{if } j\omega = 0 \\ \pm j\bar{\omega}_{p1}, \pm j\bar{\omega}_{p2} & \text{if } j\omega = \pm j\omega_p \\ \pm j\bar{\omega}_{a1}, \pm j\bar{\omega}_{a2} & \text{if } j\omega = \pm j\omega_a \end{cases}$$

- In effect,
 - the origin of the s plane maps onto point $j\omega_0$ of the \bar{s} plane,

- Thus,

$$j\bar{\omega} = \begin{cases} j\omega_0 & \text{if } j\omega = 0 \\ \pm j\bar{\omega}_{p1}, \pm j\bar{\omega}_{p2} & \text{if } j\omega = \pm j\omega_p \\ \pm j\bar{\omega}_{a1}, \pm j\bar{\omega}_{a2} & \text{if } j\omega = \pm j\omega_a \end{cases}$$

- In effect,

- the origin of the s plane maps onto point $j\omega_0$ of the \bar{s} plane,
- points $\pm j\omega_p$ of the s plane map onto points $\pm j\bar{\omega}_{p1}, \pm j\bar{\omega}_{p2}$ of the \bar{s} plane,

- Thus,

$$j\bar{\omega} = \begin{cases} j\omega_0 & \text{if } j\omega = 0 \\ \pm j\bar{\omega}_{p1}, \pm j\bar{\omega}_{p2} & \text{if } j\omega = \pm j\omega_p \\ \pm j\bar{\omega}_{a1}, \pm j\bar{\omega}_{a2} & \text{if } j\omega = \pm j\omega_a \end{cases}$$

- In effect,

- the origin of the s plane maps onto point $j\omega_0$ of the \bar{s} plane,
- points $\pm j\omega_p$ of the s plane map onto points $\pm j\bar{\omega}_{p1}, \pm j\bar{\omega}_{p2}$ of the \bar{s} plane,
- points $\pm j\omega_a$ of the s plane map onto points $\pm j\bar{\omega}_{a1}, \pm j\bar{\omega}_{a2}$ of the \bar{s} plane, and


- Thus,

$$j\bar{\omega} = \begin{cases} j\omega_0 & \text{if } j\omega = 0 \\ \pm j\bar{\omega}_{p1}, \pm j\bar{\omega}_{p2} & \text{if } j\omega = \pm j\omega_p \\ \pm j\bar{\omega}_{a1}, \pm j\bar{\omega}_{a2} & \text{if } j\omega = \pm j\omega_a \end{cases}$$


- In effect,

- the origin of the s plane maps onto point $j\omega_0$ of the \bar{s} plane,
- points $\pm j\omega_p$ of the s plane map onto points $\pm j\bar{\omega}_{p1}, \pm j\bar{\omega}_{p2}$ of the \bar{s} plane,
- points $\pm j\omega_a$ of the s plane map onto points $\pm j\bar{\omega}_{a1}, \pm j\bar{\omega}_{a2}$ of the \bar{s} plane, and
- $\pm\infty$ of the s plane maps onto $\mp\infty$ of the \bar{s} plane.

LP-to-BP Transformation – Mapping Properties



LP-to-BP Transformation – Graphical Illustration



Lowpass-to-Bandstop Transformation

- The LP-to-BS transformation follows the pattern of the LP-to-BP transformation.

Analog-Filter Transformations *Cont'd*

- The analog-filter transformations have the following important features:

Analog-Filter Transformations *Cont'd*

- The analog-filter transformations have the following important features:
 - The passband and stopband in the normalized filter yield corresponding passband(s) and stopband(s) in the denormalized filter, respectively.

Analog-Filter Transformations *Cont'd*

- The analog-filter transformations have the following important features:
 - The passband and stopband in the normalized filter yield corresponding passband(s) and stopband(s) in the denormalized filter, respectively.
 - The maximum passband loss, A_p , and minimum stopband loss, A_a , of the normalized filter are preserved in the denormalized filter.

Analog-Filter Transformations *Cont'd*

- The analog-filter transformations have the following important features:
 - The passband and stopband in the normalized filter yield corresponding passband(s) and stopband(s) in the denormalized filter, respectively.
 - The maximum passband loss, A_p , and minimum stopband loss, A_s , of the normalized filter are preserved in the denormalized filter.
 - Parameter λ scales the passband or stopband edge of a denormalized lowpass or highpass filter relative the passband or stopband edge of the normalized filter.

Analog-Filter Transformations *Cont'd*

- The analog-filter transformations have the following important features:
 - The passband and stopband in the normalized filter yield corresponding passband(s) and stopband(s) in the denormalized filter, respectively.
 - The maximum passband loss, A_p , and minimum stopband loss, A_s , of the normalized filter are preserved in the denormalized filter.
 - Parameter λ scales the passband or stopband edge of a denormalized lowpass or highpass filter relative the passband or stopband edge of the normalized filter.
 - Parameters ω_0 and B scale the location and passband or stopband width of a denormalized bandpass or bandstop filter.

Analog-Filter Transformations *Cont'd*

- The analog-filter transformations have the following important features:
 - The passband and stopband in the normalized filter yield corresponding passband(s) and stopband(s) in the denormalized filter, respectively.
 - The maximum passband loss, A_p , and minimum stopband loss, A_s , of the normalized filter are preserved in the denormalized filter.
 - Parameter λ scales the passband or stopband edge of a denormalized lowpass or highpass filter relative the passband or stopband edge of the normalized filter.
 - Parameters ω_0 and B scale the location and passband or stopband width of a denormalized bandpass or bandstop filter.
- The transformations are used in Chap. 12 to design recursive lowpass, highpass, bandpass, and bandstop filters that would satisfy arbitrary prescribed specifications.

*This slide concludes the presentation.
Thank you for your attention.*